

KitchenAid®**OVEN PARTS**


For Models: KEHC309JBL08, KEHC309JWH08, KEHC309JBT08, KEHC309JSS08

(Black)

(White)

(Biscuit)

(Stainless Steel)

30" BUILT-IN ELECTRIC
DOUBLE OVEN
THERMAL CONVECTION LOWER
MICROWAVE CONVECTION UPPER

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models:KEHC309JBL08, KEHC309JWH08, KEHC309JBT08, KEHC309JSS08

(Black)

(White)

(Biscuit)


(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	7	8303099	Top Chassis	31	4449809	Screw
	8300653	Installation Instructions	8	4452492	Insulation, Top	32	4449743	Screw
	8304065	Use & Care Guide (Oven)	9	4452158	Tube, Vent	33	9760677	Deflector, Vent
	8304064	Use & Care Guide (Microwave)	10	4452163	Lens, Light	34	8302592	Vent, Center
	4453330	Cooking Guide (Lable)	11	4448972	Oven Light Assy	35	3400832	Screw
	4452967	Chart, High Speed Cooking	12	4452164	Bulb, Light	36	3196176	Screw
	8303852	Tech Sheet (Oven)	13	4452491	Insulation, Grill	37	9759243	Thermostat (TOD) (120c) SPST
	4449264	Easy Set Guide	14	9759060	Frame, Front	38	4450038	Screw
	3191638	Safer Cooking Tips	15	4455382	Gasket, Door	43	9759713	Base, Chassis
	9759133	Safer Cooking Tips	16	4452490	Spacer, Foam	49	4448933	Retainer, Gasket
2	4452152	Bracket, Mounting	17	4452337	Insulation, Bottom Vent	50	4451747	Cover, Back
3		Bottom Trim	18	4448444	Grommet	51		Trim, Bottom
		Hinge Receiver		4450583	Right Side		4455443	Black
	4455605	Left Hand		4450584	Left Side		4455445	White
	4455606	Right Hand	22	4449154	Screw		4455447	Biscuit
4	4448520	Bumper, Door	23	4449040	Screw		4455147	Stainless Steel
5		Trim, Side	24		Screw		4452152	Bracket, Mounting
		Right Hand		8281236	Black	52	4450289	Screw
	4455430	Black		694091	S.Steel	53	4451756	Chassis, Back
	4455432	White	25	4455641	Side, Chassis (R.H. & L.H.)	FOLLOWING PARTS NOT ILLUSTRATED		
	4455434	Biscuit	26	4452234	Back, Chassis			
	4452083	Stainless Steel	27		Liner, Oven (Not serviceable)	INSULATION		
		Left Hand	29	4455636	Sensor			
	4455431	Black	30	4449845	Bracket, Support		4449316	Insulation, Wrap
	4455433	White					4450365	Insulation, Back
	4455435	Biscuit						
	4452084	Stainless Steel						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models:KEHC309JBL08, KEHC309JWH08, KEHC309JBT08, KEHC309JSS08
(Black) (White) (Biscuit) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	4452604	Panel, Control Black
	4452605	White
	4452974	Biscuit
	4451791	Stainless Steel
2	8302662	Switch, Membrane Black
	8302664	White
	8302668	Biscuit
	8302666	Stainless Steel
3	3400832	Screw
4	4451592	Filter
5	4452260	Spacer, Foam
6	4451632	Bracket, Filter
7	8301991	Assy, Control
8	4449745	Screw
10	4449809	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN DOOR PARTS

For Models: KEHC309JBL08, KEHC309JWH08, KEHC309JBT08, KEHC309JSS08
(Black) (White) (Biscuit) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	9759413	Door Liner	12	4455391	Door Glass, Assy	15	9759229	Bracket(2nd Glass)
2	9760575	Hinge, Door		4455390	Black	16	9759230	Bracket(3rd Glass)
	9760576	R.Side (clear)		4455395	White	19	4457103	Shield, Heat
		L.Side (clear)		4452316	Biscuit	21	4452326	Seal, Door Top
3	4449259	Glass, Inner		4452502	Stainless Steel	22	4457114	Shield, Heat
4	4451722	Insulation, Door	13	4452503	Black	23	4450863	Retainer, Glass-Clip
5	4457132	Retainer, Glass		4452871	White		4450864	Black
6	4449809	Screw		4455851	Biscuit		4452119	White
7	9759225	Glass, Inner	14	4455803	Stainless Steel		4451432	Biscuit
8	4449743	Screw		4455804	Bracket, Handle		9759228	Stainless Steel
9	3196184	Screw			Right Hand	24		Glass, Inner
10	3400832	Screw			Left Hand			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LATCH PARTS

For Models: KEHC309JBL08, KEHC309JWH08, KEHC309JBT08, KEHC309JSS08
(Black) (White) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust
2	4455178	Elbow, Vent-Top
3	8300791	Bracket, Combo
4	4449809	Screw
5	4455177	Elbow, Vent-Bottom
6	4451758	Seal, Foam
7	4449040	Screw
8	4450408	Baffle, Rear
9	4449154	Screw
10	9760888	Latch, Motorized
15	4455191	Plate, Blower
16	6610168	Blower
19	4449906	EXT Filler

IMPORTANT PRODUCT SAFETY INFORMATION

ADVISE CONSUMERS OF AN ELECTROCUTION HAZARD WITH DO – IT – YOURSELF REPAIRS OF MICROWAVE OVENS.


The U.S. Consumer Product Safety Commission warns against do – it – yourself repairs of microwave ovens. Microwave ovens use high voltage which makes it particularly hazardous for consumers to remove the cover and touch electrical parts.

STRONGLY RECOMMEND THAT CONSUMERS HAVE PROFESSIONALS REPAIR MICROWAVE OVENS.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: KEHC309JBL08, KEHC309JWH08, KEHC309JBT08, KEHC309JSS08
(Black) (White) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	4456104	Element, Broil
2	4449154	Screw
3	4457277	Grill, Broiler
4	4457276	Pan, Broiler
5	3181534	Rack, Roasting
6	4448717	Rack, Oven
7	4452155	Element, Bake


Illus. No.	Part No.	DESCRIPTION
8	4448881	Nut, Hex
9	4451583	Convection, Motor
10	4452226	Blade, Fan
11	4448882	Washer, Lock
12	4452227	Nut
13	4451355	Jack, Meat Probe

Illus. No.	Part No.	DESCRIPTION
14	4448948	Probe, Meat
15	4455037	Tray, Bake
17	4450039	Cover, Bake Tray
18	4449809	Screw
20	4452157	Element, Convection
21	4448418	Cover, Fan

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET AND STIRRER PARTS

For Models: KEHC309JBL08, KEHC309JWH08, KEHC309JBT08, KEHC309JSS08
(Black) (White) (Biscuit) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET AND STIRRER PARTS

For Models: KEHC309JBL08, KEHC309JWH08, KEHC309JBT08, KEHC309JSS08

(Black)

(White)

(Biscuit)


(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	4375437	Bracket, Capacitor	31	4375423	Thermostat	55	4375422	Sensor, Temp.
3	4375252	Rubber Ring	32	4375281	Thermostat	56	4375420	Insulation
4	4375038	Screw	33	4375408	Q Tube Assembly	57	4375419	Duct, Heater
5	4375314	Air Duct, Magnetron	34	4375438	Transformer	58	4375416	Washer
6	4375253	Support, Tube	35	4375406	Ring, Turntable	59	4375417	Element, Heater
7	4375421	Plug, Ceramic	36	4375407	Shaft, Turntable	60	4375418	Fan
8	4375255	Bushing	39		Bracket, Hinge	61	4375429	Motor, Fan
9	4375256	Reflector		4375412	Left	62		Left-Threaded Nut
10	4375257	Chamber, Reflector		4375413	Right			Serviced With
12	4375450	Duct, Inlet	42	4375331	Plate, Grill			Motor Item 61
13	4375316	Insulation, Switch	43	4375332	Bracket	63	4375430	Thermostat
14	4375322	Fan Wheel	44	4375441	Fan Cap	64	4375431	Shield, Heat
15	4375317	Duct, Air	46		Switch Holder	65	4375432	Insulation
16	4375415	Block, Slide		4375412	Left	66	4375433	Chamber, Heat
17	4375248	Cover Plate, Upper		4375413	Right			Cabinet
18	4375251	Screw	47	4375258	Nut	67	4375437	Isolation Plate
19	4375318	Lens, Lamp	48		Insulation	68	4375338	Cover Plate
20	4375319	Spring		4375409	Left Side	71		Side Plate
21	4375320	Reflector		4375410	Right Side		4375341	Left
23	4452220	Rack	49	4375411	Plate, Side		4375342	Right
24	4393536	Crisp Plate			Bottom	72	4455919	Turntable
25	4375436	Capacitor	50	4375425	Valve	73	4375346	Switch
26	4375424	Magnetron	51	4375428	Screw To Valve	74	4375278	Motor, Turntable
27	4375321	Fuse	52	4375427	Thermoactuator	75	4375348	Lamp
28	4375231	Block, Fuse	53	4375426	Air Bleed	76	4375349	Rectifier
29	4375278	Motor, Blower	54	4375439	Shield, Heat			
30	4375279	Thermostat			Right			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MICROWAVE COMPARTMENT PARTS

For Models: KEHC309JBL08, KEHC309JWH08, KEHC309JBT08, KEHC309JSS08
(Black) (White) (Biscuit) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
5	4452551	Support Rails Right Side
	4452552	Support Rails Left Side
6	4449809	Screw
11	4452548	Rear Channel

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models:KEHC309JBL08, KEHC309JWH08, KEHC309JBT08, KEHC309JSS08
(Black) (White) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	4450378	Cover, Top
2	4448935	Baffle, Blower
3	4452003	Blower (45MM)
	4450920	Blower (1200RPM)
4	4451789	Plate, Mounting
5	4452104	Transformer, (Lights) (2)
6	4451634	Exhaust Duct
7	4450027	Bracket, Duct
8	4449964	Grommet
9	4454949	Holder, Fuse
10	4454976	Fuse


Illus. No.	Part No.	DESCRIPTION
11	4449868	Block, Terminal
12	4452559	Side, Combo
13	4456145	Vent, Control Panel
14	4451597	Side, Control Top Right
	4451598	Left
15	4452244	Back, Control
16	4450551	Cover, Top Rear
17	4448664	Clamp
18	4452367	Cover, Top Front

Illus. No.	Part No.	DESCRIPTION
19	4455038	Transformer, Control
20	4452247	Cover, Plate
21	4451934	Suppressor
22	9752759	Relay, Double Line Break
23	3400832	Screw
24	4449809	Screw
25	4449154	Screw
26	3400080	Screw
27	4450038	Screw
28	112432	Nut, Hex

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MICROWAVE DOOR PARTS

For Models: KEHC309JBL08, KEHC309JWH08, KEHC309JBT08, KEHC309JSS08
(Black) (White) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	4448937	Glass, Middle
2	8303556	Frame, Door
3	4450038	Screw
4		Bracket, Mounting
	4449141	Right Side
	4449142	Left Side
5		Filler, Side
	4449083	Right Side
	4449086	Left Side
6		Handle, Door
	4452502	Black
	4452503	White
	4452871	Biscuit
	4455851	Stainless Steel

Illus. No.	Part No.	DESCRIPTION
7		Glass, Outer
	4452211	Black
	4452789	White
	4452995	Biscuit
	4452259	Stainless Steel
8	4449809	Screw
9	4452331	Bracket, Handle
10		Retainer, Glass-Clip
	4450863	Black
	4450864	White
	4452119	Biscuit
	4451432	S.Steel

Illus. No.	Part No.	DESCRIPTION
11	4375339	Door, Plate
12	4375414	Frame, Inner
13	4375330	Strap, Door
14	4375313	Screw
15		Hinge, Door
	4375323	Left
	4375324	Right
16	4451009	Sprng,Trsn (RH)
	4452398	S.Steel (RH)
17	3196184	Screw
18	4452395	Sprng,Trsn(LH)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models:KEHC309JBL08, KEHC309JWH08, KEHC309JBT08, KEHC309JSS08
(Black) (White) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
<u>PAINT, TOUCH-UP (1/2oz.)</u>			<u>SPLICING WIRES--25FT. LENGTH</u>			<u>WIRING HARNESS PARTS</u>		
	72017	White		242828	Wire (12 Ga. 150 c Black)		8301909	Harness, Latch
	261869	Cord Brown		242820	Wire (14 Ga. 150 c Black)		4449809	Screw
	72032	Black		242821	Wire (14 Ga. 150 c Blue)		8301923	Harness, Main
<u>PAINT, SPRAY</u>				242822	Wire (14 Ga. 150 c Brown)		4450831	Ground (M/W)
	350930	White		242830	Wire (14 Ga. 200 c Brown)		4450800	Screw, Ground
	261900	Citrine White		242823	Wire (14 Ga. 150 c Green)		8303838	Harness, Main Filter
	830864	Black		242824	Wire (14 Ga. 150 c Orange)		4449809	Screw
<u>ADHESIVE</u>				242825	Wire (14 Ga. 150 c Red)		4450950	Conduit, Combo
	591014	Adhesive Loctite (1/3 oz.)		242831	Wire (14 Ga. 200 c Red)		313438	Clip, Harness
	482338	Sealer, Silastic (3 oz.)		242827	Wire (14 Ga. 150 c Yellow)		4452222	Spacer, Harness
							4454835	Tie, Cable
							4452400	Lead, Ground
						<u>Miscellaneous</u>		
							4448950	Screw, Install (4)
							814381	Hinge Pin Kit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST